

## LINKedge as a garden edge



1. Clear the area, compact and level the base.



2. Lay the LINKedge down in the approximate area you require it to be



3. Half hammer spikes into pre punched holes (approx 4 spikes every 3m length) starting from the first hole in the end of the LINKedge



4. Half hammer subsequent spikes in pivotal areas along the length. (especially at points where a bend or curve are required)



5. Connect any further 3m lengths together by using the provided fishplate. Slide the fishplate into the designated section at the end of the length.



6. Snap it together with the second LINKedge length enabling for an uninterrupted clear edge.



7. Check the position of the link edge is visually correct, if not, remove the spikes and reposition it.



8. Once satisfied with the positioning of the LINKedge, hammer spikes firmly into the ground using a hammer.



9. Place large rocks or other on one side of the LINKedge.



10. place small pebbles or other on otherside of the LINKedge. Rake into place.



And enjoy your new landscaped area.



### Disclaimer

The LINKedge product and associated items including EDGEspikes (collectively, "Product") are provided by the manufacturer (Dagenham Pty Ltd trading as Link Plus) ("Link Plus") "as is" and without express warranties of any kind. Any statements by Link Plus concerning the Product are indicative only and are intended solely to be a guide to the features and performance of the Product and any other matters referred to. The Product must be correctly used and installed to perform as indicated, and Link Plus accepts no responsibility for any failure of the Product resulting from incorrect use or installation, or for any injury, loss or damage (including personal injury or property damage) that may occur in directly or indirectly in connection with the Product. While Link Plus has endeavoured to ensure that the information made available regarding the Product is accurate, complete, and up-to-date, no guarantee is provided that this is or will be the case. By using the Product the customer acknowledges and agrees that the customer has formed the customer's own view of the suitability of the Product for the intended application solely on the basis of the factual information provided. Link Plus reserves the right to modify or discontinue the Product or any literature referring to the Product at any time without notice.

Link Plus does not exclude or limit the application of any provision of any statute, including the Trade Practices Act 1974 (Cth) ("TPA"), where to do so would contravene that statute or cause any part of this disclaimer to be void. Link Plus excludes all conditions, warranties and terms implied by statute, general law or custom, other than any condition, warranty or term the exclusion of which would contravene any statute or cause any part of this disclaimer to be void ("Non-excludable Condition"). Link Plus' liability for breach of any Non-excludable Condition is limited, at Link Plus' option, to any one of re-supplying, replacing or repairing the goods in respect of which a breach occurred. Link Plus also excludes all liability in contract for damages, including without limitation any direct, indirect or consequential damages, and all liability for negligence and other non-contractual causes of action in respect of which liability may be excluded, that may arise in connection with any use of the goods. If the customer is a consumer as defined in the Act, Link Plus does not exclude or limit its liability to the customer for breach of any Non-excludable Condition in respect of goods of a kind ordinarily acquired for personal, domestic or household use or consumption.